



SERVICE & MAINTENANCE (Continued)

6. Drain the system and then close the radiator drain valve tightly. (Install block drain plugs, if removed.)
7. Disconnect all hoses from the coolant recovery tank. Remove the tank and pour out any fluid. Scrub and clean the inside of the tank with soap and water. Flush it well with clean water and drain. Reinstall the tank and hoses.
8. Add enough ethylene glycol coolant (meeting GM Specification 1899-M) and water to provide the required cooling, freezing, and corrosion protection. Use at least a 50% solution, -34°F (-37°C), but no more than a 70% solution. Fill the radiator to the base of the filler neck and fill the coolant recovery tank to the "Full Hot" mark. Install recovery tank cap.
9. Run the engine, with the radiator cap removed, until the upper radiator hose is hot.
10. With the engine idling, add coolant to the radiator until it reaches the bottom of the filler neck. Install the radiator cap, making sure that the arrows on the cap line up with the overflow tube.

It is the owner's responsibility to:

Maintain cooling system freeze protection at -20°F (-29°C) to ensure protection against corrosion and loss of coolant from boiling. This should be done even if freezing temperatures are not expected.

Add ethylene glycol base coolant that meets GM Specification 1899-M when coolant has to be added because of coolant loss or to provide added protection against freezing at temperatures lower than -20°F (-29°C); -35°F (-37°C) in Canada.

NOTE: Alcohol or methanol base coolants or plain water alone should NOT be used in your vehicle at any time. They will boil at a lower point than that at which the hot light indicator (or temperature gauge) works, and they do not provide proper protection against corrosion.

RADIATOR PRESSURE CAP

The radiator cap, a 15 psi (105 kPa) pressure type, must be installed tightly, otherwise coolant may be lost and damage to engine may result from overheating. Radiator pressure caps should be checked periodically for proper operation. If replacement is required, an AC-Delco cap is recommended.

THERMOSTAT

The engine coolant temperature is controlled by a thermostat. It stops coolant flow through the radiator until a preset temperature is reached. This thermostat is installed in the engine coolant outlet on the engine block. The same thermostat is used in both winter and summer. When a replacement is needed, AC-Delco parts are recommended.

DRIVE AXLE/DIFFERENTIAL

Add lubricant, if needed, to fill to level of filler plug hole. Use SAE 80W or SAE 80W-90 GL-5 gear lubricant. (For those vehicles driven in Canada, use SAE 80W GL-5 gear lubricant.) You can also use GM 1052271 or 1052272 gear lubricant, available at your dealer.

TRANSFER CASE

Add lubricant, if needed to level of fill plug hole. Use recommended lubricant. Tighten fill plug to 20 ft. lbs. torque.

POWER STEERING

Check the fluid level in the pump reservoir at each oil change period.

Add GM Power Steering fluid GM No. 1050017 (or equivalent) as necessary to bring level into proper range on filler cap indicator depending upon fluid temperature.

If at operating temperature (approximately 150°F (66°C) which would be hot to the touch), fluid should be between 1/2 and 3/4 full. If at room temperature (approximately 70°F (21°C), fluid should be at the 1/2 full level. Fluid does not require periodic changing.

BRAKE MASTER CYLINDER

Check master cylinder fluid level in both reservoirs. If the fluid is low in the reservoir, it should be filled to a point about 1/4-inch below lowest edge of each filler opening with Delco Supreme No. 11 or DOT-3 fluids.

HYDRO-BOOST BRAKE SYSTEM HYDRAULIC PUMP

On vehicles equipped with power steering, the power steering pump also is used as the hydro-boost pump. See the section on the Power Steering System when checking fluid level or adding fluid.

NOTE: Power steering fluid and brake fluid cannot be mixed, since seal damage may result.

AIR CLEANER ELEMENT

When replacement of air cleaner filter element is necessary, an AC air filter element is recommended.

Operation of vehicle in dusty areas will necessitate more frequent replacement. Your dealer can be of assistance in determining the proper replacement frequency for the conditions under which you operate your vehicle.

CAUTION: If the air cleaner is removed during repair or maintenance, be sure to put it back on correctly. If the air cleaner is not correctly installed, there could be a fire in the engine compartment (if there should happen to be a backfire), or other engine malfunction.

FRONT WHEEL BEARINGS

The front wheel bearings have been engineered and selected to last at least 24,000 miles without repacking. Should a seal get damaged or leak, they should be serviced immediately.

NOTE: Tapered roller bearing used in this vehicle have a slightly loose feel when properly adjusted. They must never be over tightened (preloaded) or severe bearing damage may result. Consult your authorized dealer for service. Damage can occur if service procedures are not followed. Longfiber or viscous type greases should not be used. Do not mix wheel bearing lubricants. Never attempt wheel bearing service yourself. Have a qualified service department do it. See page 29.

FRONT SUSPENSION AND STEERING LINKAGE

Lubricate fittings with water resistant EP Chassis Lubricant which meets GM Specification 6031M.

NOTE: Ball joints should not be lubricated unless their temperature is 10°F (-12°C), or higher. During cold weather, they should be allowed to warm up as necessary before being lubricated.



SERVICE & MAINTENANCE (Continued)

CHASSIS LUBRICATION

Lubricate the following points with water-resistant EP chassis lubricant-

Steering Linkage and Suspension

1. Upper and lower ball joints — 4 fittings.
2. Bell crank — 1 fitting.
3. Idler arm — 1 fitting.
4. Drag link — 2 fittings.
5. Intermediate rod — 2 fittings.
6. Tie rods — 4 fittings.

Drive Shafts

1. Drive shaft slip joint — 1 fitting.
2. Half shafts to each front wheel:
Slip joint — 1 fitting

FRONT DRIVE SHAFTS (AXLE TO WHEEL HUB)

Lubricate inboard carden joint and slip joint. Check condition of the rubber boot over the constant velocity joint at the outboard end (wheel end) of the shaft. If grease is leaking from the boot have your dealer or service dept. change it immediately and re-pack the C/V joint.

BATTERY

Your new vehicle battery needs no periodic maintenance. Its top is permanently sealed (except for two small vent holes) and has no filler caps. You will never have to add water.

CAUTION: Follow the precautions listed in the Jump Starting Section (see the "In Case of Emergency" section (page 19), in this manual) when working on or near the battery. Personal injury (particularly to eyes) or property damage may result from battery explosion, battery acid, or electrical (short circuit) burns.

TIRES

The tires installed on your vehicle, shown on the Vehicle Certification Label, are engineered to provide a proper balance of performance characteristics for normal vehicle operation. This section contains some tips on how you can obtain the most benefit from these tires. See page 28 in this manual for "Important Information on Vehicle Loading."

TIRE INFLATION PRESSURE

The cold inflation pressures for your factory installed tires are listed on the Certification Label. Your tires must be inflated to these pressures to obtain the GVWR (Gross Vehicle Weight Rating) or GAWR (Gross Axle Weight Rating). Incorrect tire inflation pressures can have adverse effects on tire life and vehicle performance. Too low an air pressure causes increased tire flexing and heat build-up. This weakens the tire and increases the chance of damage or failure and can result in tire overloading, abnormal tire wear, adverse vehicle handling, and reduced fuel mileage. Too high an air pressure can result in abnormal wear harsh ride and also increase the chance of damage from road hazards.

Lower inflation pressures can be used with reduced vehicle loads. After finding the load on each tire by weighing the

vehicle on a scale, the minimum cold inflation pressures can be found in the Tire/Wheel Load & Inflation Pressure Chart (see page 106).

Tire inflation pressures should be checked at least monthly (including the spare if so equipped). Always check tire inflation pressures when tires are "cold."

1. The "cold" tire inflation pressure applies to the tire pressure when a vehicle has not been driven more than one mile (1.6 kilometers) after sitting for three hours or more.

2. It is normal for tire pressures to increase 4 to 8 pounds per square inch (30 to 60 kilopascals) or more, when the tires become hot from driving. Do not "bleed" or reduce tire inflation pressures after driving your vehicle. Bleeding serves to reduce "cold" inflation pressure and increase tire flexing which can result in tire damage and failure.

3. For sustained driving at speeds over 65 mph (100 km/h), where such speeds are permitted by law, cold inflation pressures should be increased 10 psi (70 kPa) above those stated in the Tire/Wheel Load and Inflation Pressure Charts for the load being carried. Do not exceed the wheel capacity limit shown in the Wheel Code and Limits Charts.

Sustained speeds over 65 mph (100 km/h) are not advised where the 10 psi (70 kPa) pressure increase would exceed the wheel capacity limit.

For special operating conditions, cold inflation pressures may be increased up to 10 psi (70 kPa) above those shown in the table. For correct inflation at load see your local tire dealer or the tire inflation specifications put out by the tire manufacturer.

CAUTION: Be sure to keep the tires properly inflated. A tire that is run while significantly underinflated will overheat to the point where the tire may blow out and/or catch fire, possibly resulting in damage to the vehicle and its contents and/or personal injury to its occupants and persons in the area.

4. For proper inflation pressures when towing trailers, see page 106 in this manual.
5. Always use a tire pressure gauge (a pocket-type gauge is advised) when checking inflation pressures. A visual inspection of tires for inflation pressures is not enough, especially in the case of radial tires. Underinflated radial tires may look similar to correctly inflated radial tires. If the inflation pressure on a tire quite often is found to be low, have your dealer correct the cause.
6. Be sure to reinstall the tire inflation valve caps, if they are so equipped, to prevent dirt and moisture from getting into the valve core which could cause air leakage.
7. If an air loss occurs while driving, do not drive on the deflated tire more than is needed to stop safely. Driving even a short distance on a deflated tire can damage a tire and wheel beyond repair.

TIRE INSPECTION AND ROTATION

1. Inspect your tires daily. Look for bulges, penetrations, cracks, cuts, and/or oil contamination. If any such damage



SERVICE & MAINTENANCE (Continued)

is found, have it inspected by a qualified tire inspector and repaired or discarded immediately, at his discretion.

2. Although your Maintenance Schedule may recommend rotating tires at 6000 mile intervals, you should only rotate tires if necessary. If the tires are wearing evenly, there is no need to rotate them. If uneven wear is experienced, it may be due to a variety of reasons. Ask your dealer for advice if uneven tire wear persists.

CAUTION: Before installing wheels, remove any build up of corrosion on the wheel mounting surface and brake drum or disc mounting surface by scraping and wire brushing. Installing wheels without good metal-to-metal contact at the mounting surfaces can cause the wheel nuts to loosen, which can later allow a wheel to come off while the vehicle is moving, possibly causing loss of control.

WHEEL/TIRE ALIGNMENT AND BALANCE

Proper front-end alignment improves tire tread mileage. Your vehicle's front-end suspension parts should be inspected often and aligned when needed. Improper alignment will not cause the vehicle to vibrate. However, improper toe alignment will cause the front tires to roll at an angle which will result in faster tire wear. Incorrect caster or camber alignment will cause your front tires to wear unevenly and can cause the vehicle to "pull" to the left or right.

Proper tire balancing provides the best riding comfort and helps to reduce tire tread wear. Out of balance tires can cause annoying vehicle vibration and uneven tire wear such as cupping and flat spots.

TIRE TRACTION

A decrease in driving, cornering, and braking traction occurs when water, snow, ice, gravel, or other material is on the road surface. Driving practices and vehicle speed should be adjusted to the road conditions.

When driving on wet or slushy roads, it is possible for a wedge of water to build up between the tire and road surface. This is known as hydroplaning and may cause partial or complete loss of traction, vehicle control, and stopping ability. To reduce the chance of traction loss, follow these tips:

1. Slow down during rainstorms or when roads are slushy.
2. Slow down if road has standing water or puddles.
3. Replace tires when tread wear indicators are showing.
4. Keep tires properly inflated.

If you equip your vehicle with snow tires, use snow tires of the same size, load range, and construction type (bias, bias-belted, or radial) as your other tires.

Snow tires should be inflated 10 psi above the cold inflation pressures for the load being carried. However, do not exceed the wheel capacity limits shown on page 102.

Vehicle speed should be limited to 65 mph (100 mn/h) with truck-type snow tires.

SNOW CHAINS

NOTE: Your REVCON is a front-wheel-drive vehicle; only mount chains to front wheels.

To prevent chain damage to your vehicle:

Install the chains as tightly as possible, then tighten again after driving 1/4 to 1/2 mile (0.4 to 0.8 kilometers).

Do not exceed 45 mph (70 km/h), or the chain manufacturer's speed limit if lower.

Drive in a restrained manner avoiding large bumps, potholes, severe turns and other maneuvers which could cause the tires to bounce up and down.

Follow the chain manufacturer's instructions.

TIRE REPLACEMENT

CAUTION: Do not mix different construction types of tires on your vehicle (such as radial, bias, and bias-belted tires) except in emergencies, because vehicle handling could be affected and may result in loss of control.

You should replace your tires when:

1. Your tires are worn to a point where 2/32 inch (1.6 millimeters) or less tread remains, or the cord or fabric is exposed. To help you detect this, your tires have built-in tread wear indicators that appear between the tread grooves when the tread depth is 2/32 inch (1.6mm) or less. When the indicators appear in two or more adjacent grooves at three spots around the tire, the tire should be replaced.




Figure 20 — Tire Tread-Wear Indicators

2. Your tire tread or sidewall is cracked, cut, or snagged deep enough to expose the cord or fabric.
3. Your tire has a bump, bulge, or split.
4. Your tire sustains a puncture, cut, or other injury that can't be correctly repaired because of the size or location of the injury.

When replacing tires, you should use the same size, load range, and construction type (bias, bias-belted, or radial) as the original tires on your vehicle (see the Certification Label). Use of any other size or type tire may affect load carrying capacity, ride, handling, speedometer/odometer calibration, vehicle ground clearance, and tire clearance to the body and chassis. If replacing only a single tire, it should be paired on the same axle with the least worn tire of the others.



SERVICE & MAINTENANCE (Continued)

WHEEL REPLACEMENT

Wheels must be replaced if they become damaged (for example: bent, heavily rusted, leak air) or if wheel nuts often become loose. Do not use bent wheels which have been straightened, and do not use inner tubes in leaking wheels which are designed for tubeless tires. Such wheels may have structural damage and could fail without warning.

The wheels originally equipped on your vehicle will provide optimum life up to the maximum load and inflation pressures shown in the Wheel Code and Limits Chart. Maximum loads, maximum inflation pressures, wheel identification codes, and wheel sizes are stamped on each wheel. Service tested and approved wheels are available from your authorized dealer. When obtaining wheels for any reason from any other source, the replacement wheels should be equal in load capacity, inflation pressure capacity, diameter, width, offset and mounting configurations to those originally installed on your vehicle.

A wheel of the wrong size or type may adversely affect load carrying capacity, wheel and bearing life, brake cooling, speedometer/odometer calibration, stopping ability, headlight aim,

bumper height, vehicle ground clearance, and tire clearance to the body and chassis. Replacement with "used" wheels is not advised: they may have been subjected to harsh treatment or very high mileage and could fail without warning.

NOTE: The use of wheels and/or tires with higher load carrying limits than originally equipped on your vehicle does not in itself increase the GAWR or the GVWR of the vehicle.

Wheels having diameters ranging from 16 through 19.5 inches that have been certified for **radial tire application** have the word "radial" stamped on the rim. Wheels in the 16 inch through 19.5 inch diameter range without the "radial" identification stamp are **not** to be used with radial tires. Because of the different stresses exerted by radial tires, these wheels could become fatigued and fail without warning.

Proper replacement wheels can be obtained from your dealer.

TIRE WARRANTY

Tires are warranted by the tire manufacturers. Warranty information is included in the manufacturer's warranty folder furnished with your vehicle.

REVCON MOTOR HOME MAINTENANCE SCHEDULE

To retain the safety, dependability, and emission control performance originally built into your REVCON, it is essential that it receive periodic inspections, maintenance, and service parts replacement.

IMPORTANT NOTE: Maintenance services should be performed by your authorized REVCON dealer or any other qualified automotive service or repair establishment which is competent to provide such services and which can be relied upon to use proper parts and practices.

In addition to the in-shop type services detailed in the schedule, this manual also includes safety checks which you, the vehicle owner or driver, should perform periodically.

EXPLANATION OF VEHICLE MAINTENANCE SCHEDULE

Presented below is a brief explanation of each of the services listed in the preceding REVCON Maintenance Schedule.

NORMAL VEHICLE USE — The owner's or driver's maintenance instructions contained in this maintenance schedule are based on the assumption that your vehicle will be used as designed:

To carry passengers and cargo within the limitations indicated on the certification label.

On reasonable road surfaces within legal operating limits, as a general rule, for at least several miles (kilometers) on a daily basis.

Unusual operating conditions will require more frequent vehicle maintenance as specified in the respective sections included below.

After each of the following maintenance services has been performed, it is recommended that you insert the month, day, and the mileage in the maintenance schedule under the appropriate "Owner Service Log" column.

SECTION A — LUBE & GENERAL MAINTENANCE

A-1 CHASSIS — Lubricate all grease fittings in front suspension, steering linkage*, and on drive axle universal joints. Lubricate transmission cable and gearshift linkage*, hood latch, hood and door hinges, parking brake cable guides*, parking linkage, propeller shaft slip joint, universal joints, and brake and throttle pedal springs. Lubricate suspension and steering linkage every 2 months or 3000 miles (4800 km) when operating under dusty or muddy conditions. Check all oil lines for leaks or damage.

A-2 FLUID LEVELS — Check level of fluid in brake master cylinder*, power steering pump*, radiator, axles, transmission and windshield washer*. Keep engine freeze protection to -34° F (-37° C) or the lowest expected outdoor temperature. Engine coolant also prevents corrosion. Large fluid loss in any of these units may point out a problem. Repair these problems promptly. A low fluid level in the brake master cylinder can indicate worn disc brake pads, and should be checked accordingly.

A-3 AXLE/CASE — Every 4 months or 6000 miles (9600 km) check front axle and transfer case and add lubricant when necessary. Lubricate propeller shaft slip joint and drive axle, and universal joint. Check vent breather on front axle and transfer case for leaks and proper installation.

A-4 DRIVE SHAFT C. V. JOINTS — Every 4 months or 6000 miles, check the boot protecting the constant velocity universal joint at the wheel end of the front wheel drive shafts. If it is leaking grease, damaged or cut, it must be replaced immediately.

* Also a Safety Service



MAINTENANCE SCHEDULE (Continued)

When to Perform Services (Months or Miles/ Kilometres, Which- ever Occurs First)	Item No.	Services (For Details, See Numbered Paragraphs)	OWNER'S SERVICE LOG Insert Month, Day and Mileage (i.e. May/5/6,000) In (Miles/Kilometres) Column Closest to Mileage When Service is Performed							
			6,000 (9 600)	12,000 (19 200)	18,000 (28 800)	24,000 (38 400)	30,000 (48 000)	36,000 (57 600)	42,000 (67 200)	48,000 (76 800)
Section A — Lubrication and General Maintenance										
Every 4 months or 6,000 miles (9 600 km)	A-1	• Chassis Lubrication	✓	✓	✓	✓	✓	✓	✓	✓
	A-2	• Fluid Levels Check	✓	✓	✓	✓	✓	✓	✓	✓
	A-3	• Axle and Transfer Case Check	✓	✓	✓	✓	✓	✓	✓	✓
	A-4	Driveshaft CV Joint Check	✓	✓	✓	✓	✓	✓	✓	✓
	A-5	* Engine Oil Change	✓	✓	✓	✓	✓	✓	✓	✓
	A-6	* Engine Oil Filter Change	✓	✓	✓	✓	✓	✓	✓	✓
	A-7	Tire Rotation	✓	✓	✓	✓	✓	✓	✓	✓
	A-8	Drive Axle Lube Change				✓		✓	✓	
	A-9	Wheel Bearings Check		✓		✓				✓
Every 12 months or 12,000 miles (19 200 km)	A-10	* Cooling System Check		✓		✓		✓		✓
Every 24,000 miles (38 400 km)	A-11	Auto. Trans. Fluid & Filter Change				✓				✓
	A-12	Power Steering Gear Check	✓	✓	✓	✓	✓	✓	✓	✓
	A-13	Drive Transfer Case Fluid				✓				✓
Section B— Safety Maintenance										
Every 4 months or 6,000 miles (9 600 km)	B-1	Owner Safety Checks	✓	✓	✓	✓	✓	✓	✓	✓
	B-2	Tire, Wheel and Disc Brake Check	✓	✓	✓	✓	✓	✓	✓	✓
	B-3	Exhaust System Check	✓	✓	✓	✓	✓	✓	✓	✓
	B-4	Suspension and Steering Check	✓	✓	✓	✓	✓	✓	✓	✓
	B-5	Brakes and Power Steering Check	✓	✓	✓	✓	✓	✓	✓	✓
Every 12,000 miles (19 200 km)	B-6	* Engine Drive Belts Check		✓		✓		✓	✓	✓
Every 12 months or 12,000 miles (19 200 km)	B-7	Drum Brakes and Parking Brake Check		✓		✓		✓		✓
	B-8	Throttle Linkage Check		✓		✓		✓		✓
	B-9	Bumpers		✓		✓		✓		✓
Section C — Emission Control Maintenance										
At 1st 4 months or 6,000 miles — then at 12 month/12,000 mile intervals	C-1	Engine Idle Speed Adjustment	✓	✓		✓		✓		✓
	C-2	Idle Stop Solenoid Check	✓	✓		✓		✓		✓
Every 12,000 miles (19 200 km)	C-3	Spark Plug Wire Check & Plug Replacement		✓		✓		✓		✓
	C-4	Engine Timing Adjust. & Distributor Check		✓		✓		✓		✓
	C-5	Air Cleaner Element Replacement		✓		✓		✓		✓
Every 12 months or 12,000 miles (19 200 km)	C-6	Carburetor Mounting Torque		✓		✓		✓		✓
	C-7	Thermo. Controlled Air Cleaner Check		✓		✓		✓		✓
	C-8	Manifold Heat Valve Check		✓		✓		✓		✓
	C-9	Carburetor Fuel Filter Replacement		✓		✓		✓		✓
	C-10	Throttle Return Control Check		✓		✓		✓		✓
	C-11	PCV System Check		✓		✓		✓		✓
Every 24 months or 24,000 miles (38 400 km)		— PCV Valve & Filter Service				✓				✓
	C-12	ECS System Check & Filter Replacement				✓				✓
	C-13	Fuel Cap, Lines and Tank Check				✓				✓
	C-14	Engine Idle Mixture Adjust				✓				✓
	C-15	EFE System Check				✓				✓
	C-16	Vacuum Advance System Check				✓				✓
	C-17	Carburetor Choke Check				✓				✓

• Also A Safety Service

*Also An Emission Control Service

✓ When to Perform Service

A-5 ENGINE OIL** — Change every 4 months or 6000 miles (9600 km), whichever occurs first, or each 2 months or 3000 miles (4800 km) when the vehicle is operated under the following conditions: (a) Dust conditions. (b) Trailer pulling. (c) Frequent idling. (d) Short trips where engine does not thoroughly warm up. Change oil and filter as soon as you can after driving in a dust storm.

A-6 ENGINE OIL FILTER** — Replace at the first oil change, and then every second oil change if mileage, 6000 miles (9600 km), determines oil change. If time (4 months) determines oil change, or you change the oil at 3000 miles (4800 km) or 2 months, replace filter at each oil change.

A-7 TIRES — To equalize wear, rotate tires as per chart above. Adjust pressures as shown on the Certification Label, under the dash. Rotate radial tires at 6000 miles (9600 km), and then each 12,000 miles (19,200 km). In addition, rotate all tires whenever you see uneven wear.

** Also an Emission Control Service.

A-8 DRIVE AXLE (DIFFERENTIAL)

On REVCON/Dana Axle, change lubricant every 24,000 miles (38,400 km). Change lubricant every 12,000 miles (19,200 km) on differential axles under severe operating conditions.

A-9 WHEEL BEARINGS — Front wheel bearings - only require repacking with grease at 24,000 mile intervals unless seals fail. Check front steering knuckle around bearing seals for excessive lubricant loss (grease buildup around seal) at each 6000 miles or 4-month period. See page 25. For rear bearings, clean and repack every 12,000 miles. Use 525⁰ high-temperature lubricant.

A-10 COOLING SYSTEM — Each 12 months or 12,000 miles (19,200 km) wash radiator filler neck and cap with clean water. Test system and cap for proper pressure capacity. Tighten hose clamps and inspect all cooling and heater hoses. Replace radiator cap if faulty. Replace hoses at 24,000 miles



MAINTENANCE SCHEDULE (Continued)

(38,400 km), or sooner if checked, swollen, or rotted. Clean outside of radiator and air conditioning condenser. Each 24 months or 24,000 miles (28,400 km), drain, flush, and refill system with new coolant as described on page 24.

A-11 AUTOMATIC TRANSMISSION FLUID — Change the transmission fluid and filter (or service the screen) every 12,000 miles (19,200 km) if the vehicle is mainly driven under one or more of these hot conditions.

In heavy city traffic where the outside temperature regularly reaches 90° F (32° C).

In hill or mountain areas.

Frequent trailer pulling.

If vehicle is not used mainly under any of these conditions, change the fluid and filter (or service the screen) every 24,000 miles (38,400 km).

A-12 POWER STEERING GEAR — Check for seal leakage around the pitman shaft and housing. If leakage is evidenced by oil oozing out — not just oily film. This should be corrected immediately.

A-13 DRIVE TRANSFER CASE FLUID CHANGE — Drain and refill with automatic transmission fluid according to instructions in chart on this page every 24,000 miles.

SECTION B — SAFETY MAINTENANCE

The owner or driver can check Items B1 (a) through (y), but only a qualified mechanic should check Items B-2 through B-9. For your safety and that of others, any of the safety items identified in this manual that may have been damaged in an accident should be checked. Make any needed repairs before driving the vehicle.

The following checks should be made each 6000 miles (9600 km) or 12 months, whichever comes first. Check more often when needed.

B-1 SAFETY CHECKS TO BE MADE BY OWNER OR DRIVER:

Promptly take any problems to a mechanic for service advice.

(a) STEERING COLUMN LOCK (IF SO EQUIPPED) —

While parked, check by trying to turn the key to "Lock" in each gear range. The key should turn to "Lock" only when gear is in "Park."

(b) STEERING COLUMN LOCK (WITH KEY RELEASE LEVER — IF SO EQUIPPED)

While parked, check by trying to turn the key to "Lock" without depressing the lever. The key should turn to "Lock" only with the key lever depressed. The key should remove only in "Lock."

(c) PARKING BRAKE — Park on a fairly steep hill and hold the vehicle with the parking brake only. This checks holding ability.

CAUTION: Before checking (d) or (e) below, be sure to have enough room around the vehicle. Then firmly apply both parking brake and regular brake. Do not use the accelerator pedal. If the engine starts, be ready to turn off the ignition switch promptly. Take these precautions because the vehicle could move without warning and possibly cause personal injury or property damage.

RECOMMENDED FLUIDS & LUBRICANTS

USAGE	FLUID/LUBRICANT
Power steering system and pump reservoir	GM power steering fluid Part No. 1050017 or equivalent
Transfer drive box	Dexron II automatic transmission fluid
Differential - standard or locking Propeller shaft slip joint	SAE-80W or SAE-80W-90 GL-5 gear lubricant (SAE-80W-GL-5 in Canada)
Brake system and master cylinder	Delco Supreme 11 fluid or DOT-3
Hood Latch assembly	a. Engine oil b. WD 40 spray or equivalent
Hood and Door hinges	Engine oil
Automatic transmission shift linkage	Engine oil
Chassis lubrication	Chassis grease meeting requirements of GM 6031-M
Engine	"SE" Engine Oil conforming to GM specs GM 6136-M
Constant Velocity Universal Joint	GM Lubricant Part No. 1050679 or grease meeting requirements of GM 6040-M
Automatic transmission	Dexron II automatic transmission fluid
Parking brake cables	Chassis grease
Front wheel bearings	Lithium base 525 ⁰ high-temperature lubricant.
Body door hinge pins, hinge and linkage, folding seat, fuel door hinge	Engine oil
Windshield washer solvent	GM Optikleen washer solvent Part No. 1051515 or equivalent
Engine coolant	Mixture of water and high quality Ethylene Glycol base type anti-freeze conforming to GM Spec. 1899-M
Key Lock Cylinders	WD-40 Spray Lubricant or equivalent

NOTE: Fluids are lubricants identified with GM part numbers or GM specification numbers may be obtained from a Chevrolet dealer.

(d) STARTER SAFETY SWITCH (AUTOMATIC TRANSMISSION) — Check by trying to start the engine in each gear. The starter should crank only in "Park" and "Neutral."

(e) Check page 19 for correct start sequence and warning light descriptions.

(f) TRANSMISSION SHIFT INDICATOR — Check that the indicator points to the gear chosen.

(g) STEERING — Be alert for any changes in steering action. An inspection or service is needed when: the steering wheel is harder to turn or has too much free play, or if there are strange sounds when turning or parking.

(h) WHEEL ALIGNMENT, BALANCE AND TIRES — Uneven or abnormal tire wear, or a pull right or left on a straight and level road may show the need for a wheel alignment. A vibration of the steering wheel or seat at



MAINTENANCE SCHEDULE (Continued)

- normal highway speeds means a wheel balancing is needed. Check tire pressure when the tires are "cold," at least monthly (include the spare). Check the pressure more often if daily check shows it's needed (see page 28 for Driver's Daily Checklist). Adjust tire pressure as needed when changing loads.
- (i) **BRAKES** — Watch for the "Brake" light coming on. Other signs of possible brake trouble are such things as: repeated pulling to one side, strange sounds when braking or between brake applications, or increased brake pedal travel. If you note one of these conditions, have the system checked promptly and repaired if needed.
 - (j) **EXHAUST SYSTEM** — Be alert for any changes in the sound of the exhaust system or any smell of fumes. These are signs the system may be leaking or overheating. Have it checked and/or repaired promptly.
 - (k) **WINDSHIELD WIPERS AND WASHERS** — Check the operation and condition of the wiper blades. Check the flow and aim of the washer spray.
 - (l) **DEFROSTERS** — Turn the control lever to "DEF" and the fan lever to "HI." Then check the air flow from the ducts at the inside base of the windshield.
 - (m) **REARVIEW MIRRORS AND SUN VISORS** — Check that friction joints will hold mirrors and sun visors in place.
 - (n) **HORN** — Blow the horn now and then to be sure it works. Check all button locations.
 - (o) **LAP AND SHOULDER BELTS (IF SO EQUIPPED)** — Check belt system, including: webbing, buckles, latch plates, retractors, light and buzzer reminders, guide loops, clips, and anchors for proper operation, and for damage.
 - (p) **SEAT ADJUSTERS** — When adjusting a manual seat, be sure that seat adjusters latch, by pushing the seat forward and back.
 - (q) **SEATBACK RECLINER** — Check to see that seatback recliner (if present) is holding, by pushing and pulling on top of the seatback while it is reclined.
 - (r) **SEATBACK LATCHES** — Vehicles with folding front seats (and folding rear seats) have mechanical seatback latches. They are designed to prevent forward motion of the seatback when the vehicle slows suddenly. Check to see that seatback latches are holding by pulling forward on the top of folding seatback.
 - (s) **LIGHTS AND BUZZERS** — Check panel lighting and warning lights (see page 15 for correct function of each warning system). On the outside, check: license plate lights, side marker lights, headlights, parking lights, tail-lights, brake lights, turn signals, backup lights, clearance lights, identification lights, and hazard warning flashers. Have headlight aim checked promptly if beams seem improperly aimed.
 - (t) **GLASS** — Check for broken, scratched or damaged glass that could reduce vision or cause injury.
 - (u) **DOOR LATCHES** — Check that doors close, latch, and lock tightly.
 - (v) **HOOD LATCHES** — Check that hood closes firmly. Check for broken, damaged, or missing parts that might prevent tight latching. Check that springs are intact and all fasteners tight or adjusted correctly.
 - (w) **FLUID LEAKS** — Check for fuel, water, oil or other fluid leaks by looking at the surface beneath the vehicle after it has been parked awhile. Water dripping from the air conditioning system after use is normal. If you notice fuel fumes or fluid at any time have the cause found and corrected promptly.
 - (x) **SPARE AND JACK** — Check that spare tire, all jack gear, and any covers or doors are securely stowed at all times.
 - (y) **UNDERBODY** — Corrosive materials used for ice and snow removal, and dust control, can collect on the underbody. If these materials are not removed, accelerated corrosion (rust) can occur on underbody parts such as fuel lines, frame floor pan, and exhaust system. At least every Spring, flush these materials from the underbody with plain water. Take care to clean well any areas where mud and other debris can collect. Sediment should be loosened before being flushed.

SAFETY CHECKS TO BE MADE BY MECHANIC:

- B-2 TIRES, WHEELS AND DISC BRAKES** — During tire rotation, check disc brake pads for wear, and surface condition of rotors while wheels are removed (see Item A-7). Check tires for excessive or abnormal wear, or damage. Be sure that wheels are not bent or cracked and that wheel nuts have been tightened to the torque value and at the intervals indicated on page 27.
- B-3 EXHAUST SYSTEM** — Check the complete exhaust system. Check body areas near the exhaust system. Look for broken, damaged, missing, or out-of-position parts. Also, inspect for open seams, holes, loose connections, or other conditions which could let exhaust fumes seep into the passenger compartment. Dust or water in the passenger compartment may indicate a leak in the area. Needed repairs should be made at once. To help maintain system integrity, replace the exhaust pipes and resonators rearward of the muffler whenever a new muffler is put on. (Also see Item B-1 (j)).
- B-4 SUSPENSION AND STEERING** — Check front and rear suspension, and steering system. Look for damaged, loose or missing parts; also for parts showing signs of wear, or lack of lubrication. Replace questionable parts at once.
- B-5 BRAKES AND POWER STEERING** — Check lines and hoses for proper hook-up, binding leaks, cracks, chafing, etc. Any questionable parts should be replaced or repaired at once. When rubbing or wear is noted on lines or hoses, the cause must be corrected promptly.
- B-6 ENGINE DRIVE BELTS** — Check belts driving the fan, air pump, generator, power steering pump, and the air conditioning compressor. Look for cracks, fraying, wear and proper tension. Adjust or replace as needed.
- B-7 DRUM BRAKES AND PARKING BRAKE** — (See Item B-2 for disc brake check.) Check drum brake linings for wear or cracks. Also inspect other brake parts at each wheel, such as drums, wheel cylinders, etc. Check parking brake adjustment also when inspecting drum brake linings.



MAINTENANCE SCHEDULE (Continued)

NOTE: Check for damaged or missing parts, interference or binding. Fix any problems at once.

B-8 THROTTLE LINKAGE — Check for damaged or missing parts, interference or binding. Fix any problems at once.

B-9 BUMPERS — Check front and rear bumper systems for proper impact protection and clearance. Check also when a bumper looks out of position or if it was struck hard - even if no damage can be seen.

SECTION C EMISSION CONTROL MAINTENANCE

C-1 ENGINE IDLE SPEED — Adjust to the specifications shown on the underhood label. You must use precise test equipment.

C-2 IDLE STOP SOLENOID AND/OR DASHPOT — Check that parts work properly. Replace them as needed.

C-3 SPARK PLUG WIRES AND PLUG REPLACEMENT — Clean wires. Remove corrosion on terminals. Check the wires for checks, burns, cracks or other damage. Check the boot fit at distributor cap and spark plugs. Replace wire if damaged or if corrosion cannot be cleaned. Replace spark plugs as shown on Maintenance Schedule, page 29.

C-4 TIMING AND DISTRIBUTOR CAP — Adjust timing to underhood label specifications. Check the inside and outside of the cap and rotor for cracks, carbon tracking and corrosion. Clean or replace as needed.

C-5 AIR CLEANER ELEMENT — Replace at mileage shown on schedule. Replace more often under dusty conditions. Ask your dealer for the proper replacement times for your driving conditions.

C-6 CARBURETOR MOUNTING — Torque mounting bolts and/or nuts at mileage shown on Maintenance Schedule.

C-7 THERMOSTATICALLY CONTROLLED AIR CLEANER — Check all hoses and ducts for correct hookup. Be sure valve works properly.

C-8 MANIFOLD HEAT VALVE — Some engines are equipped with a manifold heat valve which should be inspected and repaired as necessary to insure free operation.

C-9 CARBURETOR FUEL FILTER — Replace at mileage shown on Maintenance Schedule or sooner if clogged.

C-10 THROTTLE RETURN CONTROL (TRC) SYSTEM — Check hoses for proper connections, cracking, abrasion, or deterioration and replace as necessary. Check for proper operation of system.

C-11 POSITIVE CRANKCASE VENTILATION SYSTEM (PCV) — Check that system works properly and clean filter, if it is on the valve cover, each 12,000 miles (19,200 km). Each 24,000 miles (38,400 km), replace the valve. Replace worn or plugged hoses and filter if it is in the air cleaner. Clean filter if it is on the valve cover.

C-12 EVAPORATION CONTROL SYSTEM (ECS) Check all fuel and vapor lines and hoses for proper hookup, routing, and condition. Check that purge valves work properly, if equipped. Remove canisters, check for cracks or damage. Replace as needed. Replace canister filter.

C-13 FUEL CAP, FUEL LINES AND FUEL TANK — Check the fuel tank, cap and lines for damage or leaks. Remove

fuel cap, check gasket for an even filler neck imprint, and any damage. Replace parts as needed.

C-14 ENGINE IDLE MIXTURE — At designated intervals or in case of a major carburetor overhaul, or when poor idle quality exists, adjust mixture by a mechanical method (lean drop), following the specifications shown on the label under the hood.

C-15 EARLY FUEL EVAPORATION (EFE) SYSTEM — Check that valve works properly, and correct any binding. Check that thermal vacuum switch works properly. Check hoses for cracks, rubbing, or decay. Replace parts as needed.

C-16 VACUUM ADVANCE SYSTEM AND HOSES — Check that system works properly. Check hoses for proper hookup, cracks, rubbing or decay. Replace parts as needed.

C-17 CARBURETOR CHOKE AND HOSES — Check that choke and vacuum break work properly. Correct any binding caused by damage or gum on the choke shaft. Check hoses for proper hookup, cracks, rubbing, or decay, correct as needed.

TRAILER TOWING TIPS

GETTING STARTED

Before entering traffic with a trailer equipped with electric brakes, start the vehicle and trailer moving and apply the trailer brakes by hand to be sure the trailer brakes are working and the trailer electrical system is connected.

CAUTION: Before going down a steep or long grade, reduce speed and shift the transmission into a lower gear to control your vehicle's speed. Try not to hold the brake pedal down too long or too often. This could cause the brakes to get hot and not work as well.

LONG UPHILL GRADES

When going up long grades, you can reduce the chance of engine overheating by down-shifting the transmission to a lower gear and reducing speed to 45 mph (70 km/h) or below.

PARKING

You should not park your REVCON with a trailer on a grade (hill). However, if you must park on a grade, these steps must be followed:

1. Apply regular brakes.
2. Have someone place wheel chocks under trailer wheels.
3. When wheel chocks are in place, release regular brakes until chocks absorb load.
4. Apply parking brake.
5. Place transmission in "PARK."

CAUTION: If the REVCON is parked on a grade, don't shift the transmission lever to "PARK" until the trailer wheels are chocked and the parking brake is set. If you do, the weight of the vehicle and trailer may exert so much force on the parking pawl in the transmission that it may be hard to get the shift lever out of "PARK."

When starting, after being parked on a grade:

1. Apply regular brakes and hold until steps 2 and 3 (immediately preceding) are completed.
2. Start engine in "PARK."
3. Shift into gear and release parking brake.
4. Release regular brakes and drive until the chocks are free.
5. Apply regular brakes and have helper remove chocks.




Figure 21 – Outside Fiberglass Body Parts Diagram

REVCON FLUID SPECIFICATIONS

Engine Oil and Filter Change:

Dry Fill	7 Quarts
Oil Change with Filter	6 Quarts
Oil Change without Filter	5 Quarts

Oil Filter Location and Type:

Location — Backside of main crossmember

Type: Fram PH 8A

Quaker State QS 8A

AC PF2

GM 6435675

Motorcraft FL-1

Radiator:

Capacity	30 Quarts
(Dry fill including rear auto heater and water heater Heat Exchanger)	

Transmission Hydramatic 475:

Capacity	14 Quarts
(Complete overhaul)	

Transfer Case:

Capacity (Dextron II)	1 1/8 Quarts
-----------------------	--------------

Differential-

Capacity	7.2 pints
----------	-----------



WINDSHIELD REPLACEMENT — To gain access to the sealed edges of the windshield, the top, side, center, and cowl fiberglass trim must be removed.

1. Separate the side trim from the cowl at the parting line (see figure A), by cutting the fiberglass and/or plastic filler with a hacksaw or other suitable tool.
2. Remove the drip-rail over the windshield to expose the top trim rivets.
3. Drill out the top trim rivets and pull the top and side trim away from the body. There are also rivets in the side trim which will become apparent as the trim is pulled away. Some plastic filler (see illustration) will be broken away as the side trim is removed.

4. The cowl must be removed by detaching at the fender and at the firewall lip.
5. Remove center trim which is sealed in place with rubber adhesive plus a single screw (see illustration).
6. The windshield edges are now exposed to allow standard removal and installation procedures.
7. Reinstallation of trim will require the repair of those areas cut during removal.

- 1) Rubber Sealant
- 2) Attaching Screw
- 3) Access Door
- 4) Top Trim
- 5) Center Trim
- 6) Break plastic filler here
- 7) Parting line between side trim and cowl trim




Figure A — Windshield Replacement